


Maestro Waste and Overflow installation instructions



Overflow Installation



**Loosen 2 screws from
overflow mounting bracket**



**Install overflow backing
plate on angle on side at
a time**



**Center overflow backing
plate with overflow
mounting bracket**



**Using Phillips head
screw driver tighten
screws evenly**



**Insure that center holes
align. Place small
amount of silicone to
overflow face plate stud**



**Screw in overflow cover
leaving approx. 3/16 gap
from tub wall to
overflow plate**

Drain Installation



Apply Plumbers putty or silicone to the bottom side of the flange on strainer



Install to bath, Insure that holes on drain are not obstructed



While holding pressure inside tube, install rubber gasket over brass threads



Continue holding pressure inside tube while threading on A.B.S. Direct drive shoe hand tighten ¼ turn past hand tight