

# Hydro Systems Blower Operation

## TURNING AIR BLOWER ON

- Press the (A) blower button to start the air blower, to change the speeds keep depressing (A) on the blower icon to reduce the speeds from 6 to 1
- Press (B) to turn OFF the air blower
- After 30 minutes, Blower turns OFF unless it has been turned off manually

## TURNING LED LIGHTS ON (Optional)

- Press the Light icon button to start the LED lights by pressing the lights ON
- To select a desired color press ON/OFF for 4 seconds to select a color
- After 30 minutes, LED lights turn OFF unless it has been turned off manually

## PURGE CYCLE ACTIVATES BLOWER

- Press the (B) Blower icon button to start the the air blower
- Automatically turns OFF after 30 minutes
- After system has been shut off the blower will start the purge cycle. It will start in medium speed for 60 seconds then automatically switch to high speed to remove all the remaining water from your thermal air channel, at this point you will not be able to shut the system off it will automatically shut off

## TROUBLE SHOOTING

If blower does not activate, perform the following tests:

### POWER/OUTLET CHECK

- Check blower controller connection
- Test outlet with lamp or electrical device
- Check GFCI breaker or reset breaker

### AIR BLOWER BUTTON DOESN'T ACTIVATE



- Check power to blower (as above)
- Check cable for proper connection

### BY-PASS CONTROLLER CHECK

- Plug air blower directly into a working outlet
- If equipment runs, proceed to bath controller check
- If pump or blower does not run, contact customer support

### BATH CONTROLLER CHECK

- Check or test outlet (as above)
- Check panel cable for proper connection
- Check to make sure all jumpers are connected (for any component cables not being used)
- If pump or blower operates when directly powered, contact customer support



# H | S

HYDRO SYSTEMS

**Headquarters**  
29132 Avenue Paine  
Valencia, CA 91355

**Manufacturing Facility**  
385 Highway 155 South  
McDonough, GA 30253

**Technical Support**  
support@hydrosystem.com

**Orders Department**  
orders@hydrosystem.com

**General Information**  
info@hydrosystem.com

**Phone:** 661-775-0686  
**Website:** hydrosystem.com

